

Knowledge Transfer Notes (01/14/2020)

2 ipynb files — training
 — inference.

Training Notebook.

- Using Detectron (uses pytorch)
- 12 hrs of colab training.
- loss was peaking and dropping
- drive linking to stop time wast.
on uploading files to colab.
- colab.patches → to display
images in colab.
- json — contains annotations

- coco dataset format is used.
- 2 dataset files - 800 + 400
= 1200 images
in total.
- dataset-catalog \Rightarrow Image info
in each category and other
info.
- base_model = R_50_FPN_3x
- Once training is done, the
"outputs" folder will contain the
frozen trained model (created in
some checkpoint / when ~~no~~ epochs were
complete) in ".pth" format
- config file can be saved in a
".pkl" file. So every time we don't

need to re-write the config again.

- Once training is done we then go to the inference notebook.
- In inference notebook we load the model and the config'.pkl' file.
- the inference notebook works with the video for inferencing - so most of video handling is present here.

Some Issues.

- ① More than 60,000 epochs resulted in increased false-positive
- ② Annotation format might not work

out of the box with other models.

① Training - GPU

Inference - CPU only (no GPU).

End Product !!
oo

↳ 1) Classifier

2) Mask (Imp!!)
oo

